



Figure 2. Uncover

Figure 3. Suspend

* Steel,zinc alloy,surface nickel plated
* Push this switch,rotate,
can accomplish the result of picture 3
* Adjust*screws to attain the best result
* Three installation results(See Figures)

Soft Down Stay

Bearing Capacity Instruction

1.Put screws on the wood

plate




Figure 1. Push up

